

# Rittal – The System.

Faster – better – everywhere.

Crimping machine R8-I

4051.021

Operating instructions

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

FRIEDHELM LOH GROUP



## Contents

|      |   |    |
|------|---|----|
| 1    | About this documentation.....                               | 4  |
| 2    | General safety instructions .....                           | 6  |
| 2.1  | Intended use.....   | 6  |
| 2.2  | Processable material and crimping form.....                 | 6  |
| 2.3  | Safety equipment.....                                       | 6  |
| 2.4  | Personnel.....  | 7  |
| 3    | Unit description .....                                      | 7  |
| 3.1  | Technical specifications .....                              | 8  |
| 3.2  | Rating plate.....   | 9  |
| 4    | Transporting and installing the automatic machine .....     | 10 |
| 4.1  | Installation site.....                                      | 10 |
| 4.2  | Transporting an automatic machine.....                      | 10 |
| 4.3  | Unpacking the delivery .....                                | 10 |
| 4.4  | Scope of supply .....                                       | 10 |
| 4.5  | Installing connections .....                                | 10 |
| 5    | Configuring the automatic machine .....                     | 11 |
| 5.1  | Inserting wire end ferrules .....                           | 12 |
| 5.2  | Inserting the feeding funnel.....                           | 13 |
| 5.3  | Replacing the wire end ferrule reel .....                   | 13 |
| 5.4  | Performing the insulation stripping test .....              | 14 |
| 5.5  | Setting the cut depth .....                                 | 14 |
| 6    | Operating the automatic machine .....                       | 15 |
| 6.1  | Normal operation.....                                       | 15 |
| 6.2  | Inserting a conductor .....                                 | 15 |
| 6.3  | Touch display and operating menus.....                      | 15 |
| 6.4  | Resetting the daily counter .....                           | 16 |
| 6.5  | Switching the operating mode.....                           | 17 |
| 6.6  | Displaying counters and the machining time.....             | 17 |
| 6.7  | Setting the language .....                                  | 17 |
| 6.8  | Service display.....  | 18 |
| 6.9  | Switching off the automatic machine.....                    | 18 |
| 7    | Cleaning and maintaining the automatic machine .....        | 18 |
| 7.1  | Cleaning the automatic machine exterior .....               | 18 |
| 7.2  | Maintaining the automatic machine .....                     | 19 |
| 7.3  | Maintenance schedule.....                                   | 19 |
| 7.4  | Maintaining the conductor holding tongs.....                | 20 |
| 7.5  | Maintaining the stranded wire fixing unit.....              | 21 |
| 7.6  | Maintaining the insulation stripping unit.....              | 21 |
| 7.7  | Maintaining the crimping tool.....                          | 22 |
| 7.8  | Cleaning the interior .....                                 | 23 |
| 7.9  | Maintaining the tool unit.....                              | 23 |
| 7.10 | Maintaining the compressed air maintenance unit .....       | 24 |
| 8    | Troubleshooting.....  | 25 |
| 8.1  | Malfunction table.....                                      | 25 |
| 8.2  | Wearing parts.....  | 25 |
| 8.3  | Replacing the insulation stripping blade .....              | 26 |
| 8.4  | Replacing fuses.....  | 27 |
| 9    | Decommissioning and disposal of the automatic machine ..... | 28 |
| 9.1  | Decommissioning the automatic machine.....                  | 28 |

---

|     |  |    |
|-----|--|----|
| 9.2 | Disposing of the automatic machine ..... | 28 |
| 10  | Pneumatic diagram .....                  | 29 |
| 11  | Electric diagram .....                   | 30 |
| 12  | Conformity .....                         | 32 |

## 1 About this documentation

The warnings in this documentation are structured differently depending on the severity of danger.



**Warning!**

**Risk of fatality!**

Notices with the signal word "Warning" warn you about situations which could lead to fatal or severe injuries if you do not pay attention to the specified notices.



**Caution!**

**Risk of injury!**

Notices with the signal word "Caution" warn you about situations that could lead to injury if you do not pay attention to the specified notices.

**Attention!**

**Property damage!**

Notices with the signal word "Attention" warn you about dangers that could result in property damage.

Situation-related warnings may contain the following warning symbols:

| Symbol | Meaning   |
|--------|---|
|        | Warning: Dangerous voltage                            |
|        | Warning: Injury to hands due to sharp blades          |
|        | Warning: Injury to hands (crushing)                   |
|        | Work may be performed only by a qualified electrician |
|        | Perform work only with personal protective equipment  |
|        | Notes on documentation                                |

Additional formatting is used in the rest of the text which has the following meaning:



**Note:**

This constitutes information which is not related to safety, but which provides important information regarding correct and effective work.

- This symbol indicates an "action point" and shows that you should perform an operation or work step.

- Enumerations are indicated with dashes.

Operating instructions in other languages can be found on our website:



Click here!

### 2 General safety instructions

#### 2.1 Intended use

The automatic machine is designed for insulation stripping and crimping of flexible conductors in a single workstep.

Only material described in section 2.2 may be processed with the automatic machine.

The process-secure machining can be guaranteed only for Rittal wire end ferrules; the processing of products from other manufacturers can lead to machine malfunctions and damage.

The automatic machine may be deployed only within the specified technical limits (see sections 3.1 "Technical specifications" and 3.2 "Rating plate"). Changes and conversions must not be made to the automatic machine. Warning signs must not be removed.

The intended use also includes the observance of the complete documentation. All other uses are deemed as improper. An improper use is one that is not known to the manufacturer.

Secure operation is not ensured and the manufacturer's liability is excluded for the non-observance of these specifications.

#### 2.2 Processable material and crimping form

Conductors

Flexible H05V-K and H07V-K PVC conductors with a cross-section of 0.5 – 2.5 mm<sup>2</sup>.



Note:

The only wires that are considered processable are those that have been approved by the manufacturer. For a complete list, please contact your sales partner.

Wire end ferrules

Rittal wire end ferrules on a reel: [www.rittal.com](http://www.rittal.com)

Crimping form

Trapezoidal (standard)



#### 2.3 Safety equipment

The automatic machine is equipped with the following safety equipment:

- Safety switch inside on the front panel
- 3/2-way valve
- Mains connector

This safety equipment must not be disabled. It must be checked annually by a service technician.

The automatic machine must not be operated in the event of a malfunction.

## 2.4 Personnel

Only personnel familiar with the machine may operate the automatic machine and perform maintenance tasks. The familiarisation also includes reading the operating instructions completely.



Repairs may be performed only after consultation with Rittal Service and only by a qualified electrician.



Keep these operating instructions at a safe place for future reference by operating personnel when needed.

## 3 Unit description



Fig. 1: Front view

### Legend

- 1 Sleeve feeding funnel
- 2 Front panel latch
- 3 Touch display
- 4 Conductor feeding funnel with insert
- 5 Front panel
- 6 Waste chute
- 7 Carrying handle (on both sides)
- 8 Compressed-air maintenance unit
- 9 Wire end ferrule reel
- 10 Reel holder

## 3 Unit description

EN




Fig. 2: Interior view

### Legend

- 1 Transport unit
- 2 Crimping unit
- 3 Sleeve holding unit
- 4 Allen key 2.5 mm
- 5 Fall-out plate
- 6 Stranded wire fixing unit
- 7 Insulation stripping unit
- 8 Opening chock





### 3.1 Technical specifications

|                                      | Crimping machine R8-I        |
|--------------------------------------|------------------------------|
| Drive                                | electro-pneumatic            |
| Power supply                         | 1~, 100 – 240 V AC, 50/60 Hz |
| Power consumption                    | 16 VA                        |
| Fuse (mains filter module)           | 2 x T2AH250V                 |
| Maximum short-circuit current (SCCR) | 1.5 kA                       |
| Protection category                  | IP 20                        |
| Protection class                     | I / PE conductor             |
| Operating pressure                   | 5.5 bar                      |




|                                       | Crimping machine R8-I  |
|---------------------------------------|--|
| Air consumption                       | approx. 0.9 nl / limit stop  |
| Conductor insertion length            | 35 mm (1.37")  |
| Crimping length                       | 8 mm (0.31")   |
| Wire end ferrules                     | 0.5 – 2.5 mm <sup>2</sup> (AWG 20 ... 14)                                  |
| Crimping form                         | Trapezoidal  |
| Cycle time                            | 1.5 s  |
| Ambient temperature                   |  |
| Operation                             | +5 °C to 40 °C   |
| Storage/transport                     | -25 °C to +55 °C (short-term +70 °C)                                       |
| Environmental conditions              |  |
| Operating environment                 | Operation in closed and dry spaces / work-shops                            |
| Internal temperature during operation | max. 45 °C   |
| Max. operating altitude               | 2000 m above mean sea level  |
| Humidity                              | 50% at +40 °C (without condensation), 90% at +20 °C (without condensation) |
| Contamination level                   | 2  |
| Continuous sound pressure level       | < 70 dB(A)   |
| Dimensions (W x D x H)                | 390 x 330 x 460 mm (15.35" x 12.99" x 18.11")                              |
| Colour                                | RAL 9003 / RAL 7016  |
| Weight                                | 23 kg (50.71 lbs)  |

## 3.2 Rating plate

| Symbol  | Meaning   |                              |
|---|---|------------------------------|
|  | Operate automatic machines only in closed and dry spaces / workshops.                               | IEC 60417                    |
|  | Reference to the accompanying information or that attached to the product. Directive 2003/15/EC     | European Union               |
|  | CE labelling  | European Economic Area (EEA) |
|  | The number of years that the product can be used for the intended use. SJ/T 11363-2006 (China RoHS) | China                        |

## 4 Transporting and installing the automatic machine

EN

| Symbol  | Meaning  |        |
|---|--|--------|
|  | Marked product must not be disposed of as household refuse. WEEE directive | Europe |

### 4 Transporting and installing the automatic machine

#### 4.1 Installation site

The installation site must satisfy the following requirements:

- Stable base with flat, level surface (automatic machine weight, see section 3.1 "Technical specifications").
- At least 30 cm free work surface on both sides and in front of the automatic machine.
- Connection for electricity and compressed air easily accessible near the machine.
- The ergonomic principles as standing or sitting workstation follow.
- The workstation illumination should lie in the range 500 – 1000 lux.



**Note:**

The optimum operating pressure is 5.5 bar ( $\pm 0.5$  bar). Adequately good crimping results cannot be achieved with less than 5 bar operating pressure.

Increased wear on the automatic machine can occur with more than 6 bar operating pressure.

#### 4.2 Transporting an automatic machine



**Caution!**

- Always wear work shoes with foot protection when transporting the automatic machine.

- Before transportation, always empty the waste container.
- Consider the weight of the automatic machine (see section 3.1). If necessary, use a transport aid.
- Always use the side carrying handles to move the automatic machine.
- To prepare the automatic machine for shipping (e.g. for servicing), use the transport packaging.

#### 4.3 Unpacking the delivery

- Check the delivery for completeness (see section 4.4 "Scope of supply").
- Retain the transport packaging.
- Ensure that the operating instructions are always available for users.

#### 4.4 Scope of supply

- Insulation stripping and crimping machine
- Mains connection cable (10 A, 250 V)
- Compressed air hose
- Allen key 2.5 mm
- Operating instructions
- Feeding funnel (3 sizes)

#### 4.5 Installing connections

- Install the automatic machine at the envisaged location.



Fig. 3: Installing connections

### Legend

- 1 Adjusting screw
- 2 Manometer
- 3 Compressed air connection
- 4 Mains connection socket

- First connect the compressed air hose to the compressed air maintenance unit of the automatic machine (fig. 3, item 3).
- Then connect the compressed air hose with the compressed air source.
- Check the manometer display (fig. 3, item 2).  
The operating pressure must be between 5 and 5.5 bar.
- If necessary, adjust the operating pressure by pulling the adjusting screw upwards (fig. 3, item 1) and turning it carefully:
  - Turn clockwise to increase the pressure.
  - Turn counter-clockwise to decrease the pressure.
- Insert the mains cable in the mains connection socket (fig. 3, item 4) of the automatic machine and connect it to the power supply.

## 5 Configuring the automatic machine

The automatic machine must be configured for the following situations:

- When a different type of wire end ferrule should be processed

## 5 Configuring the automatic machine

EN

- For every configuration

If you want to change to a different wire end ferrule type, you must first remove any wire end ferrules still in the crimping unit. Proceed as follows:

- Remove the wire end ferrule reel.
- Continue to feed the deployed conductor into the automatic machine until only the conductor is stripped of insulation.

All wire end ferrules have now been removed from inside the crimping unit.

The following settings must be checked, and modified when required, for every configuration:

- Wire end ferrule reel
- Sleeve cross-section



Note:

The automatic machine must be switched off when configuring.

### 5.1 Inserting wire end ferrules

- Place the wire end ferrule reel (fig. 4, item 1) so that clockwise unrolling is possible.
- Turn the latch (fig. 4, item 2) on the front panel (fig. 4, item 3) so it opens.




Fig. 4: Wire end ferrule reel

#### Legend

- 1 Wire end ferrule reel
- 2 Front panel latch
- 3 Front panel




Fig. 5: Transport unit

### Legend

- 1 Transport slider
- 2 Transport lever pin
- 3 Release button
- 4 Sleeve position below the transport lever

- Press the release button (fig. 5, item 3) to the right.
- Insert the belt until a sleeve is below the transport lever (fig. 5, item 4).
- Release the release button.
- Press the transport slider (fig. 5, item 1) once, and thus also the transport lever pin (fig. 5, item 2) down, until two sleeves are located below the transport lever.
- Check for correct seating by pulling carefully at the wire end ferrule belt.
- Close and latch the front panel.
- Roll up the loose wire end ferrule belt.

### 5.2 Inserting the feeding funnel

The feeding funnel must be changed for the following situations:

- When a conductor with a different cross-section is to be processed.

Conductor cross-sections are assigned to each letter:

- A = 0.5 – 0.75 mm<sup>2</sup>
- B = 1 – 1.5 mm<sup>2</sup>
- C = 2.5 mm<sup>2</sup>

Retain the feeding funnel at a suitable location near the machine.

- Remove the feeding funnel.
- Insert the new feeding funnel until a click can be heard.

### 5.3 Replacing the wire end ferrule reel

- Turn the latch on the front panel front so it opens.
- Swivel the front panel downwards.
- Press the release button to the right.

## 5 Configuring the automatic machine

EN

- Press the transport lever pin downwards.
- Pull the wire end ferrule belt out of the transport unit.
- Insert wire end ferrules, see section 5.1 "Inserting wire end ferrules".

### 5.4 Performing the insulation stripping test

You should perform an insulation stripping test every time the material to be processed has been changed.

- Switch on the mains switch.
- Set "Insulation stripping operation" operating mode on the touch display (see section 6.5 "Switching the operating mode").
- Insert a conductor for insulation stripping.
- Check the result:
  - Are all stranded wires undamaged?
  - Has the insulation been stripped straight and uniformly?
- Check with one of the uncrimped wire end ferrules whether the stripping length is correct and whether the selected combination of conductor and sleeve matches optimally.

### 5.5 Setting the cut depth

Depending on the hardness and thickness of the insulation, it may be necessary to modify the cut depth for the insulation stripping.

This requires that the cutter separation is changed by adjusting the two cams.

- To reach the cams, press the tool unit backwards and swivel it to the right.




Fig. 6: Insulation stripping unit

Legend

1 Cam screw

- Loosen the two cam screws (fig. 6, item 1) (Allen key 2.5 mm).
- To decrease the cut depth, adjust the two cams in the "+" direction (larger cutter separation).
- To increase the cut depth, adjust the two cams in the "-" direction (smaller cutter separation).
- Retighten the two cam screws.



Note:

The settings for both cams must match.

## 6 Operating the automatic machine

### 6.1 Normal operation

- Insert the wire end ferrule reel.



Note:

- Before each switch on, check:
  - Does the automatic machine have no visible defects and damage?
  - Is the mains connection cable undamaged?
  - Is the compressed air hose undamaged?
  - Is the required operating pressure (5.5 bar) present?
  - Is the front panel closed?

The automatic machine must not be operated if any of these faults is present.

- Check whether the fault can be rectified with maintenance. Otherwise, contact your Rittal Service.

- Switch on the mains switch.

The valves actuate audibly and homing is performed. The touch display shows operational readiness.

### 6.2 Inserting a conductor



Note:

- Process only conductors cut cleanly. All stranded wires must terminate flush with the insulation; no stranded wire may be shortened or protrude.
- Ensure that the conductor end is inserted straight.




Fig. 7: Insert conductor correctly

- Insert a conductor in the feeding funnel.

The material is fed slightly and machined automatically, whereby valve noises can be heard.

- Withdraw the machined conductor once the machining has completed (no further noises).

### 6.3 Touch display and operating menus

The touch display shows the current operating state. The lower part of the display is touch-sensitive.

The four control keys can be used to navigate through the program.



Fig. 8: Touch display, selection menu display

| Key | Functions                                      |
|-----|--|
| ↑   | Select menu (move forwards) or increase value  |
| ↓   | Select menu (move backwards) or decrease value |
| C   | Exit menu (return to Menu 1)                   |
| E   | Activate selected menu or set value            |

- To select an operating menu, press the arrow keys.
- To switch to the selected menu, press E.
- Within a menu, press the arrow keys to move to the desired item.
- To activate a selected item, press E.
- To exit the menu, press C.

Only menus 1, 3 and 10 are relevant for operation.

Menus:

- Menu 1: Reset daily counter
- Menu 3: Switch operating mode (standard: crimping and insulation stripping)
- Menu 10: Set language

The other menus are provided only for the Service.

### 6.4 Resetting the daily counter

- Select Menu 1, unless it is already displayed.

|  |  |
|--|--|
| 1. Production menu   |  |
| Ready  | Unit is operational  |
| Daily count: 5   | Daily counter:<br>Number of items machined since the last reset. |
| Step: 1/0  |  |
| <div> <div>↑</div> <div>↓</div> <div>C</div> <div>E</div> </div> |  |

- To reset the daily counter, press C for at least 5 seconds.  
The daily counter is set to zero.



## 6.5 Switching the operating mode

### ■ Select Menu 3.

The current operating mode is displayed.

|  |   |  |
|--|---|--|
| 3. Insulation stripping menu                                     |   |  |
| Insulation stripping:  | 0 | 0 = Insulation stripping and crimping<br>1 = Insulation stripping only |
|  |   |  |
|  |   |  |
| <div> <div>↑</div> <div>↓</div> <div>C</div> <div>E</div> </div> |   |  |

### ■ To switch the operating mode, press E.

The selected operating mode is active immediately.

### ■ To return to the production menu, press C or select a different menu with the arrow keys.

## 6.6 Displaying counters and the machining time

### ■ Select Menu 4.

|  |         |  |
|--|---------|--|
| 4. Op. data menu   |         |  |
| Tot. counter:  | 400002  | Total counter: Number of completed work cycles                               |
| Mach. time:  | 1.946 s | Machining time: Duration of a work cycle (insulation stripping and crimping) |
| Service:   | – 1     | Sign and service counter   |
| <div> <div>↑</div> <div>↓</div> <div>C</div> <div>E</div> </div> |         |  |

The total counter counts the work cycles during the complete service life of the automatic machine. The service interval of the automatic machine is 400,000 work cycles. The service counter counts down starting at 400,000. The service counter is 0 once 400,000 work cycles have been completed; the service message is displayed when the automatic machine is next started (see section 6.8 "Service display"). The service counter increments again; the negative sign indicates that a counting cycle has been completed. The service technician resets the service counter to 400,000.

## 6.7 Setting the language

### ■ Select Menu 10.

### ■ To activate the menu, press E.



|  |  |
|--|--|
| 10. Languages  |  |
| -----  |  |
|  |  |
|  |  |
| <div> <div>↑</div> <div>↓</div> <div>C</div> <div>E</div> </div> |  |

## 7 Cleaning and maintaining the automatic machine

EN

- Press **↓** until the desired language is displayed.  
The selected language is accepted immediately
- To return to the production menu, press **C** or select a different menu with the arrow keys.

### 6.8 Service display

|   |   |  |
|---|---|--|
| 1. Production menu  |   |  |
| Ready   |   | Unit is operational  |
| ——— Service ———   |   | The service display appears after every 400,000 work cycles. |
| Step:            2/0  |   |  |
|  |  | C            E   |

The service display flashes three times when the automatic machine is switched on. The automatic machine is then operational.



#### Note:

To retain the performance of the automatic machine as long as possible, you should observe the prescribed service intervals:

- Minor service after 400,000 work cycles
- Major service after 800,000 work cycles

■ Contact your responsible Rittal country representative.

### 6.9 Switching off the automatic machine

- Switch off the automatic machine.  
The valve release can be heard and the display is cleared.

## 7 Cleaning and maintaining the automatic machine

### 7.1 Cleaning the automatic machine exterior

The automatic machine should be freed regularly from dust. If necessary, its exterior must be cleaned.



#### Note:

The cleaning of the interior is included in the maintenance; this may be performed only by instructed personnel.

- Ensure that the automatic machine is switched off.

#### Attention!

The display can be damaged!

Unsuitable cleaning agents can scratch or damage the display.

- Clean the display carefully either with a special cleaning cloth suitable for display surfaces or with a soft cloth and a screen cleaning agent.

- Clean the surface of the automatic machine with a moist cloth. If required, use a soap-based cleaning agent. Never use aggressive cleaning agents or solvents.

## 7 Cleaning and maintaining the automatic machine

EN

### 7.2 Maintaining the automatic machine

To ensure problem-free operation, the described maintenance work (see section 7.3 "Maintenance schedule") must be performed at the specified intervals.



#### Warning!

Risk of fatality due to electric shock!

Uninsulated parts can be touched when working inside the automatic machine.

- Switch off the automatic machine.
- Remove the compressed air hose first from the compressed air source and then from the maintenance unit.
- Disconnect the mains connector.
- Open the front panel and place it down carefully.



#### Note:

To ensure easy access to all interior areas of the automatic machine, you should remove the waste container before beginning maintenance work. Do not forget to replace the waste container after completing the work.



#### Note:

Keep the following at hand for maintenance work:

- Allen key set
- Brush and cleaning cloth
- Lubricant
  - PTFE oil
  - Lubricating grease (suitable for roller bearings)

### 7.3 Maintenance schedule

| Maintenance point | Interval / maintenance task   | See section |
|-------------------|---|-------------|
|                   | Daily   |             |
| 1                 | Check machine for waste residues  |             |
|                   | Weekly  |             |
| 2                 | Clean the conductor holding tongs   | 7.4         |
| 3                 | Stranded wire fixing unit: Clean the feeding funnel   | 7.5         |
| 4                 | Perform maintenance on the insulation stripping unit, check the insulation stripping blades | 7.6         |
| 6                 | Cleaning the interior   | 7.8         |
|                   | Monthly   |             |
| 2                 | Conductor holding tongs: Oil the pivot point and the contact surfaces                       | 7.4         |
| 3                 | Stranded wire fixing unit: Oil the pivot point and the rollers                              | 7.5         |

## 7 Cleaning and maintaining the automatic machine

EN

| Maintenance point | Interval / maintenance task  | See section |
|-------------------|--|-------------|
| 5                 | Crimping tool: Rollers and sleeve holding tongs                                    | 7.7         |
|                   | Quarterly  |             |
| 7                 | Tool slide   | 7.9         |
|                   | When required  |             |
| 8                 | Compressed air maintenance unit: Drain the condensate and clean/replace the filter | 7.10        |



Fig. 9: Overview of the maintenance points

### 7.4 Maintaining the conductor holding tongs

- Clean the conductor holding tongs with a brush.

Additional monthly maintenance:

- Oil the conductor holding tongs at the pivot points (fig. 10, item 1) and at the contact surfaces (fig. 10, item 2) of the rollers.




Fig. 10: Conductor holding tongs

### 7.5 Maintaining the stranded wire fixing unit




Fig. 11: The stranded wire fixing unit at the operational position (A) and pulled forwards (B)

- Clean the feeding funnel (fig. 11, item 1) with a brush.
- If required, use a soft cloth and methylated spirits.

Additional monthly maintenance:

- Pull the stranded wire fixing unit forwards (fig. 11, item B).
- Check whether the rollers (fig. 11, item 2) are smooth-running.  
If required, oil the pivot points of the rollers.
- Oil the pivot points (fig. 11, item 3) of the stranded wire fixing unit.

### 7.6 Maintaining the insulation stripping unit

- Ensure that the stranded wire fixing unit is at the front position.
- Push the tool unit backwards and swivel it to the right.

## 7 Cleaning and maintaining the automatic machine

EN




Fig. 12: Insulation stripping unit

- Clean the area around the hole (fig. 12, item 1) with a brush.
- If required, use a soft cloth and methylated spirits.
- Check the cutters (fig. 12, item 2). If required, replace the blades (see section 8.3 "Replacing the insulation stripping blade").

### 7.7 Maintaining the crimping tool

To reach the crimping tool, you must dismantle the stranded wire fixing unit.

- Ensure that the stranded wire fixing unit is at the front position (fig. 11, item B).
- Remove the right lower screw of the stranded wire fixing unit (fig. 11, item 4).
- Remove the stranded wire fixing unit forwards carefully.
- Tilt the stranded wire fixing unit to the side and place it down carefully.




Fig. 13: Stranded wire fixing unit dismantled

Additional monthly maintenance:




Fig. 14: Crimping tool

- Check whether the rollers (fig. 14, item 1) on the crimping tool are smooth-running.
- Check whether the rollers (fig. 14, item 2) on the sleeve holdingtongs are smooth-running.
- If required, oil both locations.
- Oil the guide pin (fig. 14, item 3) of the sleeve holding unit.
- Oil the side running surfaces (fig. 14, item 4) of the sleeve holding unit.
- Reinsert the stranded wire fixing unit and tighten it.

### 7.8 Cleaning the interior

- Remove the waste container.
- Clean the interior of the automatic machine with a brush and, when required, with a vacuum cleaner.



Note:

- Never use compressed air for cleaning the interior, because small parts (e. g. stripped insulation scrap) may become unreachable inside in the automatic machine. Malfunctions and operational failure can result.

### 7.9 Maintaining the tool unit



Fig. 15: Tool slide

## 7 Cleaning and maintaining the automatic machine

EN

Quarterly:

- Pull the stranded wire fixing unit forwards.
- Lubricate the contact surface (fig. 15, item 1).
- Return the stranded wire fixing unit to its original position.

### 7.10 Maintaining the compressed air maintenance unit



Caution!

Risk of injury by electric shock!

- Ensure that the automatic machine is switched off and the mains connector is disconnected.



Caution!

Risk of injury from a slewing compressed air hose!

- Ensure that the compressed air hose is disconnected from the compressed air source.




Fig. 16: Compressed air maintenance unit

When required:

- To drain the condensate, press the drain plug (fig. 16, item 1) upwards.



- To replace the filter, unscrew the condensate container (fig. 16, item 2) and screw out the filter (fig. 16, item 3).
- Insert a new filter and retighten the condensate container.

## 8 Troubleshooting



Note:

If a malfunction cannot be rectified with the measures described here, contact Rittal Service.

### 8.1 Malfunction table

| Malfunction  | Possible cause   | Recommended measure   |
|--|--|---|
| The automatic machine cannot be switched on.                 | The power supply is interrupted  | <ul style="list-style-type: none"> <li>■ Check the mains cable and the mains connection.</li> <li>■ Check the fuses.</li> </ul>   |
| No start for inserted conductor.                             | The start sensor (S1) is blocked by stripped insulation scrap            | <ul style="list-style-type: none"> <li>■ Open the front panel.</li> <li>■ Swivel the tool unit to the right.</li> <li>■ Pull the stranded wire fixing unit forwards.</li> <li>■ Remove the scrap from the insulation stripping unit.</li> <li>■ Return all components to their initial position.</li> </ul>             |
|  | Conductor inserted incorrectly   | <ul style="list-style-type: none"> <li>■ Insert the conductor straight.</li> </ul>  |
| The wire is stripped only of its insulation but not crimped. | Operating mode "Only insulation stripping" is set                        | <ul style="list-style-type: none"> <li>■ Change the operating mode to Standard (setting "0" in Menu 3).</li> </ul>  |
|  | The settings on the automatic machine do not match the associated sleeve | <ul style="list-style-type: none"> <li>■ Check whether the settings for sleeve cross-section match the associated sleeve.</li> </ul>  |
|  | No wire end ferrule reel inserted  | <ul style="list-style-type: none"> <li>■ Insert a wire end ferrule reel.</li> </ul>   |
| Increased rejects  | Insulation stripping blades damaged or installed incorrectly             | <ul style="list-style-type: none"> <li>■ Check the seating of the insulation stripping blades (see section 7.6 "Maintaining the insulation stripping unit").</li> <li>■ Correct the seating of the insulation stripping blades or replace them (see section 8.3 "Replacing the insulation stripping blade").</li> </ul> |
|  | Stripped insulation scrap between the tool unit and the right limit stop | <ul style="list-style-type: none"> <li>■ Remove the stripped insulation scrap.</li> </ul>   |
|  | The second sleeve is located in the sleeve holding unit                  | <ul style="list-style-type: none"> <li>■ Remove the sleeve.</li> </ul>  |

### 8.2 Wearing parts

| Product                              | Model No. |
|--------------------------------------|-----------|
| Insulation stripping blade, titanium | 4050.466  |

### 8.3 Replacing the insulation stripping blade

**Warning!**

Risk of fatality due to electric shock!

Uninsulated parts can be touched when working inside the automatic machine.

- Switch off the automatic machine.
- Remove the compressed air hose from the compressed air source.
- Disconnect the mains connector.
- Open the front panel and place it down carefully.

**Caution!**

Risk of injury from sharp blades!

- Use tweezers to replace the blades.
- Dispose of the removed blades in a special container.

**Note:**

All fitted blades must be replaced for each cutter change.




Fig. 17: Insulation stripping unit

- Remove both cams (fig. 17, item 1) (Allen key 2.5 mm).
- Loosen the fastening screws (fig. 17, item 2) (Allen key 2.0 mm) and remove the cover.
- Replace all existing blades with new ones.




Fig. 18: Inserting blades

- Place each blade-pair together so that the angled edges (marked red in fig. 18) point outwards.
- Place both blade-pairs in the retainer.
- Refasten the cover.
- Fasten both cams so that they are located in position "0".
- Perform an insulation stripping test (see section 5.4 "Performing the insulation stripping test").

### 8.4 Replacing fuses

- Ensure that the automatic machine is switched off.
- Remove the mains connector.




Fig. 19: Opening the fuse box

- Lever the fuse box (fig. 19, item 1) with a flat screwdriver from the mains filter unit.
- Replace both fuses with new ones (2 x T2AH250V).
- Insert the fuse box back into the mains filter unit.

### 9 Decommissioning and disposal of the automatic machine

#### 9.1 Decommissioning the automatic machine

- Switch off the automatic machine.
- Disconnect the mains connector.
- Remove the compressed air hose from the compressed air source.
- Remove the compressed air hose from the maintenance unit.
- Open the front panel.
- Remove the wire end ferrule belt from the transport unit.
- Turn the wire end ferrule reel counter-clockwise until the wire end ferrule belt has been removed completely from the machine.
- Remove the wire end ferrule reel.
- Empty the waste container and replace it in the automatic machine.
- Close the front panel.
- Pack the automatic machine in the original packaging.

The automatic machine is now prepared for transport and disposal, if necessary.

#### 9.2 Disposing of the automatic machine

- Decommission the automatic machine as described in section 9.1 "Decommissioning the automatic machine".
- Ensure that the automatic machine is disposed of in accordance with the national and local regulations.




The disposal of the automatic machine as household refuse is not permitted.  
The automatic machine must be disposed of environmental-conform and correctly.



**Note:**  
You can send the product to Rittal for disposal. Contact your responsible country representative.


## 10 Pneumatic diagram




# 11 Electric diagram

EN

## 11 Electric diagram





## Vereinfachte EU-Konformitätserklärung / Simplified EU Declaration of Conformity



Wir  
We

**Rittal GmbH & Co. KG, Auf dem Stützelberg, 35745 Herborn**

erklären hiermit, dass die Produkte  
hereby declare that the products

**Crimppautomat R8-I – Crimp machine R8-I AS 4051.021**

(Artikel gemäß dieser Anleitung /  
Types referenced in this manual)

folgenden Richtlinien entsprechen:  
conform to the following directives:

**2006/42/EG Maschinenrichtlinie – 2006/42/EC Machinery Directive**  
**2014/30/EU EMV-Richtlinie – 2014/30/EU EMC Directive**  
**2011/65/EU RoHS-Richtlinie – 2011/65/EU RoHS Directive**

Bei einer nicht mit uns abgestimmten Änderung der Maschine verliert diese EU-Konformitätserklärung ihre Gültigkeit.  
This EU declaration of conformity shall become null and void when the assembly is subjected to any modification that has not met with our approval.

Die vollständige und unterschriebene EU-Konformitätserklärung erhalten Sie auf der Produktseite der Rittal Homepage [www.rittal.com](http://www.rittal.com).  
The complete and signed EU declaration of conformity is available at the product site of Rittal homepage [www.rittal.com](http://www.rittal.com).

FRIEDHELM LOH GROUP

SCHALTSCHRÄNKE STROMVERTEILUNG KLIMATISIERUNG IT-INFRASTRUKTUR SOFTWARE & SERVICE



# Rittal – The System.

Faster – better – everywhere.

- Enclosures
- Power Distribution
- Climate Control
- IT Infrastructure
- Software & Services

07.2021 / D-0100-00000310-01-EN

You can find the contact details of all  
Rittal companies throughout the world here.



[www.rittal.com/contact](http://www.rittal.com/contact)

RITTAL GmbH & Co. KG  
Auf dem Stuetzelberg · 35745 Herborn · Germany  
Phone +49 2772 505-0  
E-mail: [info@rittal.com](mailto:info@rittal.com) · [www.rittal.com](http://www.rittal.com)

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

FRIEDHELM LOH GROUP

