


Rittal – The System.

Faster – better – everywhere.



Vertical Cable
Management

9972927

Assembly and operating instructions

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

FRIEDHELM LOH GROUP



Parts list


Note: General hardware list, Components vary based on kit.

<u>Material number:</u>	<u>Object Description</u>	<u>Quantity</u>
0087345	Vertical Cable Manager	1
0087347	TS8 Z-Rail Mounting Bracket	1
0087571	TS IT Rail Mounting Bracket	1
0232470	SCREW 5.5x13 PAN TORX	10
0241485	SCREW M6x12 FLH TORX	2
0213174	WASHER SQUARE	2

Hardware (provided)



Screw 5.5 x 13 Pan Torx (10)




Screw M6 x 12 FLH Torx (2)




Washer Square (2)

Tools Required



Torx 25 

TORX DRIVER






Torx 30 

TORX DRIVER




VERTICAL CABLE MANAGER , TS8 Z-RAIL CONFIGURATION

- 1. ALIGN THE ROUND HOLES IN THE CABLE MANAGER WITH THE HOLES IN THE MOUNTING BRACKET (D0087347).
- 2. USING HARDWARE PROVIDED, ATTACH 3 BRACKETS TO CABLE MANAGER.
- 3. PLACE CABLE MANAGER AGAINST EIA RAIL.
- 4. USING HARDWARE PROVIDED, ATTACH THE CABLE MANGER WITH THE MOUNTING BRACKETS TO HOLES IN EIA RAIL (SEE LOCATION: A, 3 PLACES).





CABLE MANAGER INSTALLATION I
TS8 Z- RAIL CONFIGURATION



VERTICAL CABLE MANAGER , TS IT RAIL CONFIGURATION

1. ALIGN THE SQ HOLES IN THE CABLE MANAGER WITH THE HOLES IN THE MOUNTING BRACKET (D0087571).
2. USING HARDWARE PROVIDED (0213174 & 0241485), ATTACH 2 BRACKETS TO CABLE MANAGER.
3. PLACE CABLE MANAGER AGAINST EIA RAIL.
4. USING HARDWARE PROVIDED (0232470), ATTACH THE CABLE MANAGER WITH MOUNTING BRACKETS TO HOLES IN EIA RAIL (SEE LOCATION: A, 2 PLACES).





CABLE MANAGER INSTALLATION INSTRUCTIONS

TS IT RAIL CONFIGURATION

VERTICAL CABLE MANAGER, TS FRAME CONFIGURATION

1. ALIGN THE SQ HOLES IN THE CABLE MANAGER WITH THE HOLES IN THE MOUNTING BRACKET (D0087571).
2. USING HARDWARE PROVIDED (0213174 & 0241485), ATTACH 2 BRACKETS TO CABLE MANAGER.
3. PLACE CABLE MANAGER AGAINST TS FRAME.
4. USING HARDWARE PROVIDED (0232470), ATTACHED THE CABLE MANAGER WITH MOUNTING BRACKETS TO HOLES IN TS FRAME (SEE LOCATION: A, 2 PLACES).



CABLE MANAGER INSTALLATION INSTRUCTIONS

TS FRAME CONFIGURATION

Rittal – The System.

Faster – better – everywhere.

- Enclosures
- Power Distribution
- Climate Control
- IT Infrastructure
- Software & Services

Rittal Corporation

Woodfield Corporate Center
425 North Martingale Road, Suite 400 • Schaumburg, Illinois 60173 • USA
Phone: 937-399-0500 • Toll-free: 800-477-4000
Email: rittal@rittal.us • Online: www.rittal.us

Rittal Systems Ltd.

6485 Ordan Drive • Mississauga Ontario L5T 1X2 • Canada
Phone: 905-795-0777 • Toll-free: 800-399-0748
Email: marketing@rittal.ca • Online: www.rittal.ca

Rittal Mexico

Dr. Roberto Gayol 1219-1B • Col. Del Valle Sur, 03100 • Mexico, D.F.
Phone: (+52) (55) 5559-5369 • Toll-free: 01 800 8 Rittal (748.825)
Email: info@rittal.com.mx • Online: www.rittal.com.mx

8/17 • US206

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

