



WINDOW KIT INSTALLATION INSTRUCTIONS

1. MAKE A RECTANGULAR CUTOUT OF APPROPRIATE SIZE WHERE THE WINDOW IS TO BE INSTALLED, (SEE TABLE BELOW FOR RECOMMENDED CUTOUT SIZES).
2. REMOVE PAPER FROM BOTH SIDES OF WINDOW.
3. PLACE THE WINDOW IN THE FRAME INSIDE THE STUDS PERIMETER.
4. PLACE THE WINDOW AND FRAME AGAINST THE ENCLOSURE WITH THE STUDS PROTRUDING THROUGH THE OPENING.
5. ASSEMBLE THE CLAMPS AND NUTS TO THE STUDS, ALIGN THE WINDOW AND TIGHTEN NUTS 15-20 IN-LBS. TORQUE.
6. BEFORE ANY CIRCUITS ARE ENERGIZED, ALL INTERNAL AND EXTERNAL ELECTRICAL AND MECHANICAL CLEARANCES MUST BE CHECKED TO ASSURE ALL ASSEMBLED AND MOUNTED EQUIPMENT FUNCTION SAFELY AND PROPERLY.

CATALOG NO.	RECOMMENDED CUTOUT SIZE (inches)	CATALOG NO.	RECOMMENDED CUTOUT SIZE (inches)
WK0503	6 ^{-11/16} X 4 ^{-11/16}	WK1711	18 ^{-11/16} X 12 ^{-11/16}
WK0905	10 ^{-11/16} X 7 ^{-3/16}	WK2315	24 ^{-11/16} X 16 ^{-11/16}
WK1303	14 ^{-11/16} X 4 ^{-11/16}	WK2919	30 ^{-11/16} X 20 ^{-11/16}
WK1308	14 ^{-11/16} X 9 ^{-11/16}	WK3523	36 ^{-11/16} X 24 ^{-11/16}
WK1705	18 ^{-11/16} X 7 ^{-3/16}		

